

Safety Precautions



Please unplug the power connection before cleaning and maintaining



1

Please go through the manual thoroughly before operating the water cooling fan.



2

Do not open the control panel or the cover of the inverter without qualified guidance.



3

Do not operate the control panel, or touch the power plug and the cover of the inverter with wet hands.



4

Do not share the plug with other equipment because of the fan's high start-up current. Please choose an over 2.0 MM (14 AWG) extension cord set for the water cooling fan. Also, the extension cord should not be over 25 m. Connect the fan with an irregular cord set could cause short-circuit.



5

Avoid using old extension cords or sockets. Keep the wires away from heat and fire. Do not place the wires on where man or traffic crossing to prevent wire being stepped or pulled which may cause accident.



6

Do not remove the earth part of the plug. Choose a right and tight socket, do not use one without earthing. For your safety, do not change the power cord or the wiring of the control panel.

Safety Precautions



Please unplug the power connection before cleaning and maintaining



7

This unit is not capable of and should never be used to draw: (1) flammable gases, including oil gas, fuel gas, pure oxygen, hydrogen gas, etc. (2) flammable liquid, such as gas, toluene, etc. (3) dust or crystal of under 80°C fire point, including magnesium, platinum, gun powder, etc.



8

If the fan does not function well, please turn off the power and check the wire, socket, and extension cord. After checking, restart the fan after a while. If the problem is not solved, please contact where you purchase the fan or contact us to arrange repair service. Do not detach or change spare parts on your own.



9

Please place the water cooling fan on a flat ground and step on the brake button while operating. When encounter a flood damage, please unplug the fan and move it to somewhere safe.



10

When not using the cooling fan for a while, please open the drain at the bottom or turn on the auto drain to let out the water. Then turn on the fan for 1-2 hour to dry the cooling pad. After drying, unplug the fan for storage.



11

To fill the tank manually, please turn off the fan and open the ice cube entrance to fill the water. Make sure the power is away from water to prevent accident.



12

Do not face the air inlet side (the cooling pad side) to any burning or smoking object, including matches, ash, cigarette, cigar, charcoal, etc. Damages or accidents caused by the preceding issue are not cover by the warranty.



13

While operating, do not open the cover of the inverter, the cover guard of the fan, or the cooling pad on the back; also, do not touch anything to the fan to avoid accident.



14

The water cooling fans are heavy. Please be careful while moving the cooling fan, or it may cause man-injuries if bumping or overturning occurs.



15

Do not open the ice cube entrance while the fan is operating. Approaching the running fan blades would cause injuries, and could crack the blades.



16

While cleaning the cooling fan, do not spray water to the control panel or the cover of inverter to avoid damage.



17

Do not convert, disassemble, or repair the product without instruction. Damage caused by the preceding issue are not covered by the warranty. Please contact us for support.



18

Please do not convert or change the fan blades on your own to avoid accident.



19

Do not move the water cooling fan by pulling the attaching hose. This could cause fan damage.